

EXHAUST HOSE INSTALLATION GUIDE



1. Expand both sides of the exhaust hose 3" to 4"
2. Line up the grooves inside the adapter with the edge of the hose.



3. Rotate counter-clockwise until you feel resistance. Be careful not to press down on the adapter and hose as it will collapse the hose and you will need to expand it again.
4. Repeat this for the other side of the hose with your other adapter.



5. Line up the slider kit adapter hooks with the openings on your window kit.



6. Insert into the opening then slightly rotate clockwise to lock into place.



7. Slide the unit adapter onto the back of the air conditioner from right to left.