

MODEL: IM-100

Instruction on Replacing the Ice Shovel:

△ IMPORTANT: Please do not use too much force when replacing the ice shovel.

1. Remove the broken ice shovel.
2. Turn on the icemaker and wait for 10-15 seconds until the water tray moves to a position like <IMG-01>. This provides more room for replacing the ice shovel.




<IMG-01>

3. Use tools such as point pliers to remove the metal pins (IMG-01 & IMG-02). Then remove the plastic hinges.



<IMG-02>

4. Put the metal pins and plastic hinges on the new ice shovel (IMG-04).




<IMG-03>

△ **IMPORTANT:** Please make sure the plastic hinges are above the ice shovel.



<IMG-04>

5. Install the new ice shovel (IMG-05 & IMG-06).



<IMG-05>



<IMG-06>